Pantech ADR910 Marauder

USERS MANUAL

FRONT VIEW



REAR VIEW



QWERTY VIEW



Key	Description
Alt	Enters the secondary character on the right of each key
((()	Accesses the new message screen
(a	Accesses the Browser
SYM	Enters a space
≜ Shift	Enters the capital letter for each key

Key Functions

FRONT VIEW

- 1. Power/Lock Key: Press and hold to turn the phone on or off. Press to lock the phone, or to wake the screen for unlocking.
- 2. Headset Jack: Plug in an optional headset or TTY equipment.
- 3. Front Camera Lens: Used when taking self-photos or recording videos.
- **4. Homescreen:** The starting point for using your phone. Place icons, widgets and other items to customize your phone to your needs.
- 5. Menu Key: Displays options available.
- 6. Recent Apps: Displays recent applications that you used.
- 7. Microphone: Allows callers to hear your voice and when recording.
- 8. Home Key: Moves to the main Home Screen.
- 9. Back Key: Ends an application; returns to the previous menu.
- **10. Micro USB/Charger Port:** Connects the phone to a PC via a USB cable; charges phone via the USB charger.
- 11. Volume Keys: Adjusts all sound volumes.

REAR VIEW

- 1. Back Cover: Covers the battery.
- 2. Speaker: Plays ringtones, call audio when in Speakerphone mode, music and other sounds.
- 3. Rear Camera Lens: Takes pictures and records video.
- 4. Internal Antenna Area For Voice

Getting Started

The Battery

Installing the battery

- 1. Insert your finger tip into slot at the bottom of the phone and gently lift back cover to remove.
- 2. Slide the battery into the slot by aligning the contacts and press down until you hear the "click".
- **3.** Align the cover tabs with the slots on the back of the device and gently press the battery cover onto the phone until it snaps into place.

Removing the battery

- 1. Turn off your phone and remove the back cover.
- 2. Insert your fingernail into the slot and lift the battery from the compartment.



Charging the battery

1. Insert the small end of the Charger cable into the Micro USB/Charger port.

2. Plug the large end of the charger into an electrical outlet to begin charging.

A computer can be also used to charge the smartphone by connecting via a USB cable.

Any Micro SD charger will work to charge, your phone may display a message that it is not preferred, however it will charge the phone properly.

Turning Your Phone On / Off

- 1. Press and hold the Power/Lock Key at the top left of the phone until the screen lights up.
- 2. To turn off the phone, press and hold the Power/ Lock Key until the pop-up menu appears.
- 3. Tap Power off in the pop-up menu.
- 4. Tap OK to confirm that you want to turn off the phone.

Lock / Unlock Your Phone

Locking Your Phone

Press the Power/Lock Key



Unlocking Your Phone

- 2. Tap and drag the lock or application icon into the center of the circle that appears on screen.

Messaging

Send A Text

- 1. From the Home screen, touch Wessaging > New message +.
- 2. Tap the To field and enter the recipient's name, phone number or Email address.
- 3. Touch the Type to compose field and compose your message. While composing a message, touch Menu for these options:
 - · Add subject: Add a subject field to the message and enter a subject. (This option also converts the message to MMS.)
 - · Insert text: Select text from Contacts, Bookmarks or Quick Text to add to the message or just add text/message.
 - · Insert smiley: Add a text emoticon to the message.
- 4. Touch send to send the message.

Voicemail

Checking Voicemail

- 1. Touch *86 in the keypad.
- 2. Follow the voice prompt directions.

Phone Features

- 1. Tap Apps from the Home Screen and tap Settings > Wi-Fi.
- 2. Tap OFF next to Wi-Fi on the top right side of the screen to activate. The icon turns orange when the function is on.
- 3. Tap the Wi-Fi network that you want to connect.
- 4. Tap SCAN to search for other Wi-Fi networks.
- 5. Tap ADD NETWORK to add another network.

Bluetooth Function

- 1. Tap Apps from the Home Screen and tap Settings > Bluetooth.
- 2. Tap OFF next to Bluetooth on the top right side of the screen to activate. The icon turns orange when the function is on.
- 3. Tap a device that you want to connect.
- 4. Tap SEARCH FOR DEVICES to find more devices to be connected.

Accessing Internet

- 1. Tap Browser from the Home Screen.
- 2. Tap the address bar and enter a new URL.
- 3. Tap next to a suggested item below the address bar if it matches the entered URL. Tap = in the virtual keyboard to visit the new page.

Making and Answering Calls **Making Calls**

- 1. Tap Phone (from the Home Screen.
- 2. Enter the area code and the phone number. Tap + to delete the previous number. Tap and hold + to delete the whole number.
- 3. Tap \(\mathbb{\ceil}\) to dial the number.

Answering & ending a call (screen off):

- 1. Drag () to the center to answer the call.
- 2. Drag o to the center if you do not want to answer the call.
- 3. Drag on to the center to send a message to the caller.
- 4. Tap End to end the call during the conversation. After ending a call, a call summary appears.

Answering & ending a call (screen on):

- 1. Tap Answer to answer the call.
- 2. Tap Ignore if you do not want to answer
- 3. Tap Send MSG to send a message to the caller.
- 4. Tap End to end the call during the conversation. After ending a call, a call summary appears.

Camera and Video

Take Photos

Take pictures and record videos with the built-in camera. They can be saved in the Marauder™ and sent via multimedia messages.

- 1. Tap Apps from the Home Screen and tap Camera.
- 2. Tap s and select options if necessary.
- 3. Focus on the object and tap . The picture is saved automatically.



Focusing on the object



Selecting options

Record Videos

- 1. Tap Apps from the Home Screen and tap Camera. The screen changes to landscape mode by default.
- 2. Tap 6 > 1.
- 3. Tap) and select options if necessary.
- 4. Focus on the object and tap ______. To capture the screens in the middle of recording, tap
- 5. Tap 🕞 to stop recording. The recorded video would be saved automatically.
- 6. Tap the window on the right down side of the screen to see the recorded video.



Selecting options

